



260 Welter Drive
Monticello, Iowa 52310
877-596-3842
info@tanksinc.com

RLYFP

Electric Fuel Pump Relay Kit Installation Instructions

Warning! Add fuel to tank and check for leaks before installing relay kit.

1. Disconnect battery and mount the relay assembly and circuit breaker near the battery with supplied mounting hardware.
2. Attach BLACK wire to a known ground source.
3. Route the 12 gauge ORANGE fuel pump wire and connect to the positive pump lead using the supplied yellow stepdown butt connector.
4. Attach the BROWN/WHITE wire to the ECU or switched power source. This should be a 12 volt fused power source.
5. Cut and attach large RED wire to circuit breaker using supplied yellow ring terminal
6. Use the remaining length of RED wire and yellow ring terminals connect the unused post on the circuit breaker to the battery. Reconnect battery.

